

ReleaseNotes function block D1N_Home

Version	Date [yyyy-mm-dd]	Description	Editor
0.5	2016-11-10	Homing procedure works only one time if axis state is not homed. -> Bug fix in function block -> function block tested	MW
0.6	2017-07-06	After homing with homing offset $\neq 0$ position between TwinCat3 and software Lightening is different -> Bug fix in function block -> function block tested	MW
0.7	2017-11-08	Negative homing methods are not possible. -> Bug fix in function block - data type of input "HomeMode" changed from SINT to INT -> function block tested	MW